



Top View




Bottom View


UNIT LOCATIONS




**PART LOCATIONS (Top View)**




**PART LOCATIONS (Bottom View)**



ALIGNMENT AND TEST POINTS FOR RECEIVER





ALIGNMENT AND TEST POINTS FOR PLL